



SINGLE PHASE WINDING HEAD MODEL CWDE2104

This Single-Phase Winding Head is fully adjustable for single phase coils from 3" to 13" long, with a choice of 13 widths. It also features a built-in easy-to-read Scale, accurately calibrated and a polished aluminum Head. It mounts to any coil winding drive or turning device with 18" swing. Fast set-up and easy release.

PURPOSE:

The Single-Phase Coil Winding Head is designed with 13 slots, to simplify the forming of many types and sizes of coils. Coils are wound quickly and neatly due to its rigid construction and easy-to-read Scale. Winds single-phase coils from 3" to 13" long, with a choice of 13 widths. Easy-to-read Scale (calibrated in 1/2" increments) for easy setup.

ASSEMBLY:

The Single-Phase Coil Winding Head comes in three parts-Base and Heads. There are Spacers and Allen Bolts to secure the Heads. Also for your convenience we have provided an Allen Wrench to tighten the bolts. When assembled, mount the Coil Winder by its Base to a Coil Winding Machine or the face of a lathe head or other turning device with an 18" swing. It should be fastened securely so that there is no side play or wobble.

MAINTENANCE and STORAGE:

When not in use, store unit within a plastic bag.

WARRANTY:

This equipment is warranted to the original owner against defects in materials and workmanship for ninety (90) days from date of purchase. Any part found to be defective (except by overloading, misuse, neglect, fire, accident, tampering with by unauthorized serviceman, or other cause beyond the manufacturer's control), will be replaced or repaired free of charge.