



MARTINDALE

PRODUCTS

MODEL P-2 DEMAGNETIZER INSTRUCTIONS

“Pass-Through” Type:

The Model P-2 Pass-Through Demagnetizer means just that, the part(s) being demagnetized have to be passed through the encapsulated coil for the molecules of the part(s) to become disarranged and therefore demagnetized. A foot switch leaves both hands free to pass the part(s), when the demagnetizer is in use.

This unit is not intended for continuous duty operation!

It is recommended that the unit be used in cycles of approximately 20 minutes “On” (Max.) and 10 minutes “Off”.

The part(s) should be handed through the coil slowly and not passed back and forth through the coil, as this would have a tendency to magnetize the item(s) rather than demagnetize.

The operator should take precautions when wearing a watch as the magnetic field being created may have an adverse affect on the operation of the timepiece. Large (or long) items may require more than one pass to completely demagnetize.



Foot-Switch leaves
both hands free.